



# **Model Number**

NJ2-V3-N


# Features

- 2 mm flush
- Usable up to SIL2 acc. to IEC 61508

Technical Data		
General specifications		
Switching element function		NAMUR, NC
Rated operating distance	s <sub>n</sub>	2 mm
Installation		flush
Output polarity		NAMUR
Assured operating distance	sa	0 1.62 mm
Reduction factor r <sub>AI</sub>		0.25
Reduction factor r <sub>Cu</sub>		0.2
Reduction factor r <sub>304</sub>		0.7
Nominal ratings		
Nominal voltage	Uo	8.2 V (R <sub>i</sub> approx. 1 kΩ)
Switching frequency	f	0 1000 Hz
Hysteresis	Н	0.01 0.1 mm
Suitable for 2:1 technology		yes, Reverse polarity protection diode not required
Current consumption		N 0 4
Measuring plate not detected		≥3mA
Measuring plate detected		≤ 1 mA
Ambient conditions		
Ambient temperature		-25 100 °C (-13 212 °F)
Mechanical specifications		
Connection type		cable PVC , 130 mm
Core cross-section		0.14 mm <sup>2</sup>
Housing material		PBT
Sensing face		PBT
Degree of protection		IP67
General information		
Use in the hazardous area		see instruction manuals
Category		1G; 2G; 1D
Compliance with standards and di	rectives	S
Standard conformity		
NAMUR		EN 60947-5-6:2000
		IEC 60947-5-6:1999
Standards		EN 60947-5-2:2007
		IEC 60947-5-2:2007
Approvals and certificates		
FM approval		
Control drawing		116-0165F
UL approval		cULus Listed, General Purpose
CSA approval		cCSAus Listed, General Purpose
000		

## CCC approval

Dimensions




27,8

CCC approval / marking not required for products rated  ${\leq}36$  V

# Release date: 2015-04-25 23:47 Date of issue: 2015-04-26 211636\_eng.xml

Electrical Connection



Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group L www.pepperl-fuchs.com fa-in

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

ATEX 1G	
Instruction	Manual electrical apparatus for hazardous areas
Device category 1G	for use in hazardous areas with gas, vapour and mist
EC-Type Examination Certificate	PTB 00 ATEX 2032 X
CE marking	<b>C €</b> 0102
0	
ATEX marking	⟨͡∞⟩ II 1G Ex ia IIC T6T1 Ga
Directive conformity	94/9/EG
Standards	EN 60079-0:2012, EN 60079-11:2012, EN 60079-26:2007 Ignition protection "Intrinsic safety"
	Use is restricted to the following stated conditions
Appropriate type	NJ 2-V3-N
Effective internal capacitance Ci	$\leq$ 40 nF ; a cable length of 10 m is considered.
Effective internal inductance L	$\leq$ 50 $\mu$ H ; a cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!
Ambient temperature	The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1.
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed.
	The intrinsic safety is only assured in connection with an appropriate related appara- tus and according to the proof of intrinsic safety.
	The associated apparatus must satisfy the requirements of category ia.
	Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. Install the device in such a way that the resin surface is not exposed to mechanical hazards.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Protection from mechanical danger	When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.
Electrostatic charge	Additional requirements for gas group IIC. Information on electrostatic hazards can be found in the technical specification IEC/TS 60079-32-1. Avoid electrostatic charges that can cause electrostatic discharge when installing or operating the dovice.

device.

2

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



# Inductive sensor

# ATEX 2G

Instruction

# Device category 2G

EC-Type Examination Certificate CE marking

ATEX marking

Directive conformity Standards

Appropriate type Effective internal capacitance C<sub>i</sub> Effective internal inductance L<sub>i</sub> General

Ambient temperature

Installation, commissioning

### Maintenance

### Special conditions

Protection from mechanical danger

### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2032 X C  $\pounds$ 0102

🐼 II 1G Ex ia IIC T6...T1 Ga

94/9/EG EN 60079-0:2012, EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions NJ 2-V3-N ...

 $\leq$  40 nF ; a cable length of 10 m is considered.

 $\leq$  50  $\mu H$  ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. Install the device in such a way that the resin surface is not exposed to mechanical hazards.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.



# ATEX 1D

Instruction

# Device category 1D EC-Type Examination Certificate CE marking

ATEX marking

Directive conformity Standards

Appropriate type Effective internal capacitance Ci Effective internal inductance Li General

Maximum housing surface temperature

Installation, commissioning

Maintenance

Special conditions Electrostatic charge Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust ZELM 03 ATEX 0128 X €0102

⟨ Ex⟩ II 1D Ex iaD 20 T 108 °C (226.4 °F) The Ex-relevant identification may also be printed on the accompanying adhesive label.

94/9/EG

IEC 61241-11:2002: draft; prEN61241-0:2002 type of protection intrinsic safety "iD"

Use is restricted to the following stated conditions

NJ 2-V3-N ...

 $\leq$  40 nF; a cable length of 10 m is considered.

 $\leq$  50  $\mu$ H ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed.

The special conditions must be adhered to!

The maximum surface temperature of the housing is given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. The associated apparatus must satisfy at least the requirements of category ia IIB or

iaD. Because of the possibility of the danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation in the power supply and signal circuits is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

The intrinsically safe circuit has to be protected against influences due to lightning. When used in the isolating wall between Zone 20 and Zone 21 or Zone 21 und Zone 22 the sensor must not be exposed to any mechanical danger and must be sealed in such a way, that the protective function of the isolating wall is not impaired. The applicable directives and standards must be observed.

If the Ex-relevant identification is exclusively printed on the included adhesive label, this must be applied in the direct vicinity of the sensor! The surface to which the label is to applied must be clean and free from grease! The applied adhesive label must be durable adlegible to protect it against the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use.

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

